

DOLMETSCH NOVA BASS RECORDER

Thank you for purchasing this Dolmetsch Nova Bass Recorder. Most of the information you need about the care and use of this fine instrument is set out in the leaflet **ABOUT YOUR DOLMETSCH RECORDER** supplied with your recorder.

This leaflet covers 'Bass related' points that you will find helpful.

A. Your bass recorder is supplied with an 'accessories kit' comprising grease for the joints, two sets of spare key pads, a thumbrest, four small screws and a small tube of adhesive.

Use two of the screws provided to attach the thumbrest to the bass middle. The rectangular projection of the reverse of the rest locates in the slot on the back of the lower middle section. The screws should be fitted into the most convenient of the small locating holes on each side of the slot. You may need to try the bass rest in a number of positions before finding that most comfortable for you.

To replace key pads, first remove the key cap by unscrewing the securing dowel. Remove the old pad. After removing the backing sheet to expose the self adhesive surface, push the pad firmly into the key cap depression. Replace the key cap onto the instrument.

B. Certain fingerings are different from those given on the enclosed chart.

Using the convention

× for an open, uncovered hole
0 for closed thumb hole, Ø for pinched thumb hole
123 for the left hand fingers
4567 for the right hand fingers

we recommend

Low B flat does not need the fourth finger of the right hand, **0 123 4×6×**

Low D sharp, second rather than first finger of the right hand, **0 1×3 ×5××**

If you need any assistance or have any problems whether technical or musical contact us for advice or visit our Web Page on **www.dolmetsch.com**

DOLMETSCH MUSICAL INSTRUMENTS

1b, Unicorn Trading Estate, Weydown Road, Haslemere, Surrey GU27 1DN
phone: 01428-643235 fax: 08700-560190
e-mail: brian@dolmetsch.com